



## DEL MOTORIZED SOLUTIONS

(866) 44MOTOR - (215) 639.3880

[WWW.MOTORIZEDSOLUTIONS.COM](http://WWW.MOTORIZEDSOLUTIONS.COM)

1. Ensure switch or interface is in the center "OFF" position, and connect to motor leads by matching color codes.
2. Remove the protective cap covering the limit setting buttons on motor head, and replace when finished.
3. Depress fully both limit switch push buttons. They will automatically lock in the down position. Operate the switch/remote and check that the system operates correctly (only move shade up or down a few inches). Identify the UP limit switch push button. Press the switch/remote in the UP direction until the required position is reached. Set the switch/remote to "OFF" position or press stop on remote.
4. Unlock the UP limit switch push button by depressing and releasing it.
5. Repeat the above operation to set the lower limit. Check with the switch/remote that the motor stops at the up & down positions just set.
6. Always remember to affix the protective cap over the limit switch buttons.

NOTE: Tubular motors are not continuously rated. They have a built-in thermal overload device which limits their operation to approximately 5 minutes.

