

DEL Motorized Solutions

(866) 44MOTOR - (215) 639.3880
www.motorizedsolutions.com

Installation Guide for RP Receiver

The receiver has a built-in fuse for itself, however, a fuse or circuit breaker for the motor is not included and must be provided externally. Rating of this protection device must conform to the motor manufacturer's recommendation and prevailing electrical codes.

The receiver uses less than 2 Watts.

Contact rating is 120 VAC, 1/3 HP Motor, 34.8 LRA / 6 FLA.

Power connections to the RP-AU board are made as shown:

(1) Insert a small flat blade screwdriver as shown with a slight twisting action.

The screwdriver will stay in place when fully inserted.

(2) Insert the stripped wire (.21 inch) into the hole just opened.

(3) While holding the wire in place, remove the screwdriver. The wire will be held firmly.

This connector is rated for 28 AWG minimum and 12 AWG maximum, stranded or solid wire. Only 1 wire per connection.

Note: this hole is connected to the AC ground terminal and may be used to ground enclosure if desired
this wire is optional if
ground

OPEN
COMMON
CLOSE

AC IN:
Ground (green)
Hot (black)
Neutral (white)

Motor:
Ground (green)
Neutral (white) standard reversed
Motor (red/blk) open close
Motor (blk/red) close open

Showroom:
2075 Byberry Road
The Atrium, Suite 108
Bensalem, PA 19020

Factory:
111 Buck Road
Unit #900
Huntingdon Valley, PA 19006