




## DEL MOTORIZED SOLUTIONS

(866) 44MOTOR - (215) 639.3880

WWW.MOTORIZEDSOLUTIONS.COM

### “Home Run” - Wiring Guidelines for DC Receivers



Each interface has a built-in fuse for itself, but not for the motor.

Black wire connects power to the interface and should be 18 AWG 2 conductors.

Red wire connects the motor to the interface. It should be 18 AWG 2 conductors.

Note that the motor connection can be reversed by remote programming.

Yellow wire is low voltage modular telephone cord, or CAT 5 wire.

Pink wire is low voltage modular telephone cord, or CAT 5 wire.

Green wire is power supply cord (provided)

**Note that ALL receivers must be powered for any of them to work in this configuration.**