



DEL MOTORIZED SOLUTIONS

(866) 44MOTOR - (215) 639.3880

WWW.MOTORIZEDSOLUTIONS.COM

Pre-wire | wall- and ceiling-mount


Roller 100

Determine where to drill for cable access. See options below. Cable should exit from wall, ceiling or jamb on EDU side of system.

note: leave 12-18" of cable exposed.


Wall Mount

wall




ceiling

Drill for cable 1 1/4" - 2" from end of system and 2 - 2 1/2" from top of system




jamb



Drill for cable 1/2" from top top of system and 1/2" from mounting wall.


Ceiling Mount

wall




ceiling

Drill for cable 3 1/4" from end of system and 1/2" down from top of system.



jamb



Drill for cable 1/2" from top top of system and 3/4" from mounting wall.

Drill for cable 1 1/4" - 2" from end of system and 1 1/4" - 1 3/4" from back of system.